


- NOTES:**
1. ALL DIMENSIONS SHOWN ARE IN INCHES (CENTIMETERS).
  2. 54(138) MIN. SERVICE CLEARANCE IS REQUIRED ON TOP OF HEAT EXCHANGER SHELL COVER IF RELIEF VALVE AND TEE ARE NOT TO BE DISASSEMBLED IN THE FIELD DURING SERVICE.
  3. THIS DRAWING SHOWS MINIMUM RECOMMENDED SERVICE CLEARANCE DIMENSIONS.
  4. REFER TO WATER HEATER DIMENSIONAL DRAWING TO REVIEW OTHER DIMENSIONS.
  5. DHT RESERVES THE RIGHT TO MODIFY THE DIMENSIONS WITHOUT PRIOR NOTICE.
  6. ALSO CONSULT LOCAL CODES AND AUTHORITIES.



**DIVERSIFIED**  
HEAT TRANSFER, INC.

439 MAIN RD. TOWACO NJ 07082  
PHONE: (800) 221-1522 FAX: (855) 221-2400

INSTALLATION CLEARANCE DRAWING  
VISIS SUPERTHERM WATER HEATER  
STEAM TO WATER

DRAWN BY	NAME	DATE	DWG.#	REV
LY	LY	08/18/17	S-9	B
SS	SS	08/18/17		