



SINGLE UNIT INSTALLATION (BRAZED PLATE UNIT SHOWN)



MULTIPLE UNITS INSTALLATION (PLATE AND FRAME UNITS SHOWN)

NOTES:

- 1. ALL DIMENSIONS SHOWN ARE IN INCHES [CENTIMETERS].
- 2. THIS DRAWING SHOWS MINIMUM RECOMMENDED SERVICE CLEARANCE DIMENSIONS AROUND THE UNIT. LOCAL CODES AND AUTHORITIES SHOULD ALSO BE CONSULTED.
- 3. REFER TO WATER HEATER DIMENSIONAL DRAWING TO REVIEW OTHER DIMENSIONS.
- 4. DHT RESERVES THE RIGHT TO MODIFY THE DIMENSIONS WITHOUT PRIOR NOTICE.
- 5. *CLEARANCE DIMENSION VARIES DEPENDING UPON PLATE AND FRAME UNIT MODEL SELECTED.





439 MAIN RD. TOWACO NJ 07082

PHONE: (800) 221-1522

FAX: (855) 221-2400

INSTALLATION CLEARANCE DRAWING

SUPERPLATE WATER HEATER

WATER TO WATER

	NAME	DATE	DWG.#	REV
DRAWN BY	НН	08/21/2018	S-11	В
CHECKED BY	SS	08/24/2018		