





**\*\*TERMINAL BLOCKS ARE DOUBLE-LEVEL TYPE\*\***



- NOTES:**
1. UNIT SHUTS DOWN UPON LOSS OF ELECTRICAL POWER SUPPLY.
  2. DO NOT ROUTE COMMUNICATION WIRING AND MAIN POWER WIRING INSIDE SAME CONDUIT.
  3. INSTALL EXTERNAL DEDICATED SINGLE POLE, 10 AMP SHUTOFF SWITCH & CIRCUIT BREAKER IN SERIES WITH THE ELECTRICAL POWER TO THE CONTROL PANEL OF THE UNIT.
  4. CONSULT LOCAL AND NATIONAL ELECTRICAL CODES AND STANDARDS.
  5. ADJUST DIP SWITCH SETTINGS ON CONTROL VALVE AS SHOWN ON THIS DRAWING.
  6. FAULT RELAY HAS ONE SET OF NORMALLY OPEN CONTACTS AND ONE SET OF NORMALLY CLOSED CONTACTS AVAILABLE FOR FIELD CONNECTIONS.

DIP SWITCH SETTINGS			
1	2	3	4
UP	UP	UP	DOWN

**DIVERSIFIED**  
HEAT TRANSFER, INC.

439 MAIN RD. TOWACO NJ 07082  
 PHONE: (800) 221-1522 FAX: (855) 221-2400

SP SERIES		ELECTROMAGNETIC CONTROL VALVES	
ELECTRICAL WIRING DRAWING			
NAME	DATE	DWG.#	REV
SS	05/13/2019		
CHECKED BY	PR	05/14/2019	S-36
			E